



# Nokia 6350-1b Logic board Replacement

A new logic board could be the solution to a lot of issues with your Nokia 6350-1b and it is relatively inexpensive and easy to replace. This guide will show you how to replace your Nokia 6350-1b logic board

Written By: Adrianna





## TOOLS:


- [T5 Torx Screwdriver](#) (1)



## PARTS:

- [New Nokia 6350-1b Logic Board](#) (1)

## Step 1 — Taking off the plastic frame



- Using a plastic pry, get between the plastic frame and the rest of the phone.
- Move it along the frame unlocking the locks that keep the frame in place.
- Remove the plastic frame.

 Be careful not to pry too hard and crack the plastic frame.


## Step 2 — Removing the screen cover



- Using a T-5 screw driver, unscrew the screws on the four corners of the phone.
  - Using a pry, get between the screen cover and the rest of the phone.
  - Move along this layer unlocking the various locks that keep it in place.
  - Carefully remove the screen cover to reveal the logic board.
- ⚠ Keep track of the four small screws. They will be needed to put the phone back together.



### Step 3 — Removing broken logic board



- Disconnect the flex cable from the logic board.
- Disconnect the camera from the logic board.
- Disconnect the LCD display screen.
- Disconnect the LCD phone screen.
- Carefully remove the broken logic board by freeing it from the various locks holding it in place.

⚠ Be careful not to touch either of the screens. You can leave finger prints and damage the screens.

### Step 4 — Replacing Logic Board



- Take the new logic board and connect all the parts you just disconnected to their correct locations.

## Step 5



- Place the cover so that it is in the correct position to be re-installed.
- Press gently on the cover so that it snaps back into place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 03:39:35 AM.